



CUSTOM OVERSIZED BILLET MARKER LIGHT COVERS FOR THE HUMMER H2

IMPORTANT: Read And Understand All Instructions Before Installation • QUESTIONS? CALL 1-800-982-1180

Tools Needed: Phillips Screwdriver

Time To Install: Approx. 15-20 Minutes



STEP 1

STEP 1. Remove screws and marker light.



STEP 3

STEP 3. Screw billet aluminum marker light cover back onto the vehicle.



STEP 2

STEP 2. Carefully position billet aluminum marker light cover over marker light and onto the vehicle.



STEP 4

STEP 4. View your brand new custom billet aluminum marker light covers.



REALWHEELS COVER COMPANY, INC.

3940 Tannahill Drive • Gurnee, IL 60031

847-662-7722 • Fax 847-662-7744 • www.realwheelsacc.com

info@realwheelsacc.com • toll-free 1-800-982-1180

Hummer and H2 are registered trademarks of General Motors Corporation and are used for identification purposes only.
RealWheels Cover Company, Inc. and its products are not affiliated with General Motors Corporation products.