

FRONT AND REAR CUSTOM LED LIGHT PACKAGE FOR THE HUMMER H2

IMPORTANT: Read And Understand All Instructions Before Installation • QUESTIONS? CALL 1-800-982-1180

Tools Needed: Drill, Phillips Screwdriver, 1/2" and 1/4" drill bit

Time to install front and rear: Approx. 30-40 Minutes.

Front Custom LED Light Package



1. POSITION



2. DRILL



3. INSTALL LED LIGHT



4. INSTALL BEZEL & WIRE

STEP 1. Peel off the two way tape backing from the stainless steel insert piece and position into the corner section of the bumper. **Note:** Front shown in photo at left — Rear shown in photo at right.

STEP 2. Using the stainless steel insert piece as a template, drill two 1/4" holes and one 1/2" hole into the plastic bumper. **Note:** Front shown in photo at left — Rear shown in photo at right.

STEP 3. Place the LED light wires through the previously drilled center hole. Then install two screws and nuts (provided) and tighten the LED light into place. **Note:** Front shown in photo at left — Rear shown in photo at right.

STEP 4. Install the chrome plated bezel. Then splice into the closest marker circuit. **Note:** Front shown in photo at left — Rear shown in photo at right. Repeat for other side.

Rear Custom LED Light Package



1. POSITION



2. DRILL



3. INSTALL LED LIGHT



4. INSTALL BEZEL & WIRE

REALWHEELS COVER COMPANY, INC. • 3940 Tannahill Drive • Gurnee, IL 60031 • 847-662-7722 • Fax 847-662-7744
www.realwheelsacc.com • info@realwheelsacc.com • toll-free 1-800-982-1180

Hummer and H2 are registered trademarks of General Motors Corporation and are used for identification purposes only.
RealWheels Cover Company, Inc. and its products are not affiliated with General Motors Corporation products.